PROFESSIONAL GROUP **58 LUNDHILL ROAD WOMBWELL**

using 360 degree excavator — USING EXCAVATOR TO DEMOLISH BUNGALOW

HAZARD	HAZARD EFFECT	SEVERITY	PROB	RISK	MINIMIZE RISK BY	RESIDUAL RISK
ACCESS AND EGRESS OF VEHICLE	FRACTURES / SPRAINS / BRUISING	MED	LOW	MED	ALWAYS USE THE THREE POINTS OF CONTACT RULE. BE AWARE OF UNDERFOOT CONDITIONS	LOW
MACHINE OVERTURN	FATAL / CRUSHING / FRACTURES	HIGH	MED	HIGH	USE ONLY AUTHORISED & TRAINED DRIVERS. USE CORRECT & WORTHY MACHINE. BE AWARE OF GROUND MOVEMENT & STABILITY	LOW
SLIPPING / STUMBLING / FALLING	MAJOR INJURY. REPORTABLE	HIGH	MED	MED	ESTABLISH AND MAINTAIN TIDY WORKING AREA AND CLEAR WALKWAYS. WEAR PPE AT ALL TIMES. TAKE EXTRA CARE WHEN ON UNEVEN OR WET GROUND.	LOW
DEVIATION FROM METHOD STATEMENT	MAJOR INJURY. REPORTABLE	HIGH	HIGH	HIGH	ANY DEVIATION FROM THE METHOD STATEMENT MAY ONLY BE DONE AFTER AGREEMENT WITH THE OFFICIAL ON SITE AND AN ON-SITE RISK ASSESSMENT MUST BE CARRIED OUT AND RECORDED IN CONJUNCTION WITH HIM.	LOW
LACK OF JOB CONTROL	MAJOR INJURY. REPORTABLE	HIGH	HIGH	HIGH	ALL MEN TAKING PART IN ANY WORKS REQUIRING METHOD STATEMENT MUST HAVE GONE THROUGH IT AND UNDERSTOOD IT PRIOR TO STARTING ANY WORKS. NO JOB WILL COMMENCE WITHOUT A CHOSEN INDIVIDUAL TO CONTROL IT.	LOW
PEDESTRIANS	FATAL / BROKEN BONES / SPRAINS	HIGH	MED	HIGH	GOOD HOUSEKEEPING. WORK AND TRAVEL AT A SAFE SPEED. EXCLUSION ZONE REQ'D. PEDESTRIANS TO ALWAYS WEAR CORRECT PPE.	LOW
OPERATING MACHINE INCORRECTLY	FATAL / BROKEN BONES / SPRAINS	HIGH	LOW	HIGH	ONLY FULLY TRAINED / AUTHORISED PERSON TO OPERATE MOBILE PLANT. MAKE SURE ALL LIGHTS AND REVERSE AIDS ARE IN WORKING ORDER. ALWAYS WEAR YOUR SEAT BELT	LOW
ELECTRICITY	DEATH	HIGH	LOW	LOW	NO UNAUTHORISED PERSON TO WORK ON ANY ELECTRICAL EQUIPMENT. FOLLOW ISOLATION PROCEDURE BEFORE WORKING ON ELECTRICAL EQUIPMENT. FOR PLANNED WORK, ENSURE PJIS HAS BEEN ISSUED AND THAT THE CONTROL MEASURES THEREIN ARE ADHERED TO..	LOW
DEVIATION FROM PLANNED JOB INSTRUCTION	DEATH. MAJOR INJURY. REPORTABLE	HIGH	HIGH	HIGH	NEVER DEVIATE, YOU NEED A NEW PLANNED JOB INSTRUCTION SHEET IF YOU NEED TO DEVIATE FROM THESE INSTRUCTIONS	LOW
HIGH PRESSURE PIPES	H.P.I. INJURY	HIGH	MED	LOW	DEPRESSURISE USING AUTHORISED PERSONNEL BEFORE WORKING ON ANY HIGH PRESSURE RANGE. PROVE RANGE IS DEPRESSURISED BEFORE STARTING WORK. INFORM APPROPRIATE PEOPLE / POST NOTICES AT STOP VALVES TO PREVENT INADVERTENT REPRESSURISATION.	LOW
WORKING NEAR HIGH PRESSURE RANGE / HOSES	H.P.I. INJURY	HIGH	MED	LOW	IF THERE IS RISK OF DAMAGE TO HIGH PRESSURE PIPES OR HOSES FROM THE OPERATION IN PROGRESS, TAKE STEPS TO PREVENT DAMAGE TO PIPES / HOSES OR ISOLATE & DEPRESSURISE TO MAKE SAFE FOR OPERATIVES.	LOW
ELECTRICITY	DEATH	HIGH	LOW	LOW	NO UNAUTHORISED PERSON TO WORK ON ANY ELECTRICAL EQUIPMENT. FOLLOW ISOLATION PROCEDURE BEFORE WORKING ON ELECTRICAL EQUIPMENT. FOR PLANNED WORK, ENSURE PJIS HAS BEEN ISSUED AND THAT THE CONTROL MEASURES THEREIN ARE ADHERED TO..	LOW

Kevin Broomhead/Danny Glavey

Date:- August 19 2022

OVERALL RISK IF METHOD STATEMENT AND RISK ASSESSMENT ARE ADHERED TO : LOW