

ORDNANCE SURVEY

Scale: 1:2500 or 25/344 inches to 1 Mile

Revised July 1959
Levelled 1930


Revised July 1959
Levelled 1930

The West half of this sheet is Plan SE 2206
The East half of this sheet is Plan SE 2306

PLAN SE 2206 & 1

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel. It is important
when identifying a parcel to specify the number(s) of the plan(s) on which it falls.
IN PARCELS DIVIDED BY THE SHEET EDGE, THE
ACREAGES ARE SHOWN TO SHEET EDGE ONLY.

PLAN SE 2206 & PLAN SE 2306



Made and published by the Director General of the Ordnance Survey, Chessington, Surrey, 1960.
Reconstructed from former County Series plans. Revised 1959.

R.P. & M. EMMOTT GUNTHWAITE HALL
GUNTHWAITE
PENISTONE HOLDING N° 47-619-0007

© Crown Copyright 1960

The West half of this sheet is Plan SE 2206
The East half of this sheet is Plan SE 2306

Antiquities (site of)	Bench Mark	Surface Level
Change of boundary marking	Revision Point	Revision Point or Traverse Station
Limit of area within which the acreages of individual parcels are not shown	Parcels joined for acreages	Tranquilisation Station

Leveling Information
Altitudes of Bench Marks and Surface Levels are given in feet above the Newlyn Datum.
Bench Mark lists, containing fuller and possibly later leveling information, are obtainable from the Director General, Ordnance Survey.

Base of Bank	Centre of Old Course of Stream	Face of Wall
Centre of Bank	Centre of Road, etc.	Side of River, etc.
Centre of Canal, etc.	Centre of Stream	Track of Hedge
Centre of Drain, etc.	4 feet from Root of Hedge	Track of Stream
Centre of Covered Stream	Face of Fence	Defaced, Underflood

REFERENCE
For fuller information see Reference Card published separately.

NATIONAL GRID REFERENCE
The lines on the plan form part of the National Grid and are spaced at 100 metre intervals.
To give a large scale reference the position of a point in the nearest 10 metres is given as follows—

EASTING	NORTHING
Take west edge of square in which point lies and read the figures opposite this line on NORTH and SOUTH margins.	Take north edge of square in which point lies and read the figures opposite this line on EAST and WEST margins.
Extend one tenth of metres from the grid line	Estimate tenths of metres from the grid line
EXAMPLE: NO. 2211064	EXAMPLE: 0614

TEN METRE REFERENCE: SE 2211064

For further information see "The Projection for Ordnance Survey Maps and Plans and the National Reference System".
The projection on this plan is the Transverse Mercator projection, based on the datum of 1936.

Beer House	Bull	Guide Post	Signal Bridge
Bench Mark	Boundary Pillar	Level Crossing	Signal Post
Boundary Stone	Cart Track	Mile or Meeting Post	Spring
Cart Track	Disking Fountain	Police Telephone Pillar	Stone
Disking Fountain	Electricity Pole, Post or Pylon	Police Telephone Pillar	Sundial
Electricity Pole, Post or Pylon	Flagstaff	Post Office	Tank or Trough
Flagstaff	Foot Bridge	Public House	Telephone Call Box
Foot Bridge	Footpath	Public House	Traverse Station
Footpath	High or Low Water Mark of Medium Tides	Signal Box	Water Point
High or Low Water Mark of Medium Tides		Signal Box	Water Tap
		Signal Box	Weighbridge
		Signal Box	Well
		Signal Box	Wind Pump
		Signal Box	High or Low Water Mark of Ordinary Spring Tides

PARCEL NUMBERS AND ACREAGES
The number and acreage of each parcel of land is shown within the parcel.
In parcels divided by the sheet edge, the acreages are shown to sheet edge only.

PLAN SE 2206 & 1

1 ACRE = 0.405 HECTARES